




xPRESS

Audio Keypad

Direct Control for Any Sonos® Device.



WiFi



Battery
Powered



Decora®
Compatible

Use on the Wall
or in Your Hand

Control Any Sonos Device Directly Over WiFi



Access Your Favorite Music with the Push of a Button




Set Up an xPRESS Audio Keypad in Three Easy Steps


1 Add Your Keypad
to Your Network



2 Assign your Keypad
to a Sonos Device



3 Choose a Great
Spot to Install
Your Keypad



iPort

Learn more at iportproducts.com/xpress